

Vehicle Protective Cover Package Installation

Installation Instructions Part Number

84423180

Kit Contents

Qty	Description
1	Vehicle Cover
1	Storage Bag
1	Grommet (if applicable)
1	Installation Instructions

Warning: Never use this cover on your vehicle after your vehicle has been painted within the last three months. The paint must cure completely for this period of time prior to installing your cover.

Warning: Do not cover your vehicle when your vehicle is in-tow or when your vehicle is towed on an open flat-bed trailer.

Warning: Never expose you vehicle to high winds with the vehicle cover installed.

Warning: Do not install the cover on a wet vehicle when the temperature is below freezing as the cover may freeze onto the vehicle.

Failure to observe these warnings will result in damage to your vehicle.

Note: A vehicle cover locking cable, part number 12344218, is available from your vehicle dealer to secure your cover from theft.

Procedure

1. Installing Your Vehicle Cover – Once the engine has been turned off, allow the vehicle to cool for at least 20 minutes before installing your cover. Look for the tag labeled 'front' sewn into the hem to locate the front of the vehicle cover. Place the cover on the hood and roll it back across the roof until completely unrolled. Slip the antenna opening over the antenna if applicable.* Fold the cover down each side of the vehicle and then over the trunk and hood. Hook the elastic under the front and rear bumpers.

Caution: Do not place cover near hot mufflers or exhaust pipes.
2. Removing Your Vehicle Cover – Remove the cover from the rear bumper and fold up about two feet of material toward the roof. Repeat this process with the front of the vehicle. Fold each side onto the roof. Continue until you have approximately an 18" strip of cover over the center of the vehicle. Roll the cover tightly and store it in the provided storage bag.
3. Care and Cleaning – Your vehicle cover is made of Snugfit material which is a knitted polyester fabric. This fabric is intended to cover your vehicle when stored in a garage only. If an area becomes soiled, use an all-purpose cleaner to rub it out, and rinse the area with water. **Do not machine wash. Do not machine dry. Air dry only.**

Note: You may either remove the antenna prior to installing the vehicle cover or install the grommet provided to accommodate the antenna. To install the grommet, locate the point at which the antenna will pass through the cover and mark with an "X". Using a sharp knife, cut the shape of the "X". Both cuts should not exceed 3/4 inch (19mm). Place one half of the two piece grommet on one side of the "X" with the second half on the opposite side. Snap the two halves together.